

## TECHNICAL DATA SHEET

Order No. 458-1030

Item/Model SARO Salamander Grill

model ORPHEUS

GTIN 4017337048663



- Material: polished stainless steel

- Grill: nickel-plated iron

- Grill plastic handle: heat-resistant plastic

- Top heat (2 independent, shielded heating elements)

- Adjustable temperature and independent knobs for each shielded heater

- Removable drip tray

- Removable grill with plastic handles

- 3 pairs of U-rails to adjust the level of the grill

- Inclusive crumb tray

- Weight: 19 kg

- Dimensions: W 800mm x T 410mm x H 355mm

- temp. +35 / +120 °C

- Conn.: 230 V - 50 Hz - 3 kW

Origin Portugal customs tariff no. 85167200

Stand: 06.03.2025

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY



## SAFETY & WARNING INSTRUCTIONS

Order No. 458-1030

Item/Model SARO Salamander Grill

model ORPHEUS

GTIN 4017337048663



## Safety and Warning Instructions

- Place the device exclusively on a stable, level, and heat-resistant surface.
- Ensure that the mains voltage matches the specifications on the rating plate.
- Children and unauthorized persons must not operate the device or be left unattended near it.
- During operation, the device's surfaces, particularly the tray and heating elements, can become very hot risk of burns. Use appropriate protective gloves.
- Never clean the device with a water jet or immerse it in liquids to avoid short circuits and electric shocks.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- Do not operate the device near flammable materials or in damp environments.
- Do not block or cover the ventilation openings to prevent overheating.
- Do not operate the device with a damaged cable or plug.
- Repairs must only be carried out by qualified personnel.
- Before operation, ensure that the tray is properly inserted.
- Do not switch the device on or off with wet hands to avoid the risk of electric shock.
- Regularly clean the device, particularly the tray and rack, to maintain hygienic conditions.
- The device is intended exclusively for gratinating food; any other use may cause damage and compromise safety.
- Do not use extension cords or T-adapters to connect the device.
- Dispose of packaging materials safely and keep them out of reach of children, as they pose a suffocation hazard.
- If water enters the device, disconnect it from the power supply and ensure it is completely dry before the next use.
- Do not leave the device unattended during operation.

Origin Portugal customs tariff no. 85167200

Stand: 06.03.2025

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY