

TECHNICAL DATA SHEET

Order No. **395-1038**

Item/Model **SARO Planetary mixer
model PR 10**

GTIN **4017337395064**



- **Material: (housing) steel, powder coated, (bowl, safety guard and mixing devices) stainless steel**
- **3 mixing tools included (beater, dough hook and, balloon whisk)**
- **For approx. 3 kg dough**
- **3 speeds**
- **Bowl: Ø 244 x H 285 mm**
- **Weight: 69 kg**
- **Dimensions: W 445mm x T 366mm x H 645mm**
- **Conn.: 230 V - 50 Hz - 0,45 kW**

Origin China

customs tariff no. 84381090

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. **395-1038**

Item/Model **SARO Planetary mixer
model PR 10**

GTIN **4017337395064**



Safety and Warning Instructions

- Place the device only on a stable, level, and non-slip surface.
- Ensure the mains voltage matches the specifications on the nameplate.
- Children and unauthorized persons must not operate or be unsupervised near the device.
- Keep hands, hair, clothing, and objects like spoons or spatulas away from the mixing bowl and attachments during operation.
- Immediately discontinue use if the device or cable shows visible damage, and contact qualified personnel.
- Do not immerse the device in water or clean it with a water jet to prevent short circuits and electric shock.
- Always switch off, unplug, and allow the device to cool completely before cleaning, maintenance, or extended non-use.
- Use only the provided mixing tools and accessories. Using unsuitable parts may damage the device.
- Do not remove or tamper with the device's safety features, such as the protective guard.
- Do not open the protective guard during operation, as it poses a risk of injury.
- Repairs must only be performed by qualified personnel.
- Avoid using aggressive or alcohol-based cleaning agents to protect the device's surfaces.
- The device is intended exclusively for indoor use and processing food items like dough, eggs, or creams. Any other use may cause damage and void the warranty.
- Regularly inspect the power cord for damage. A damaged cord must not be used.
- Do not move the device during operation. Always unplug it before transporting or repositioning.
- Dispose of packaging materials such as plastic bags or Styrofoam safely and out of children's reach to prevent choking hazards.

Origin China

customs tariff no. 84381090

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827