

TECHNICAL DATA SHEET

Order No. 458-1025

Item/Model SARO Salamander Grill
model ATHENA

GTIN 4017337048656



- Material: polished stainless steel
- Grill: nickel-plated iron
- Grill plastic handle: heat-resistant plastic
- Top heat
- Adjustable temperature
- Timer up to 15 minutes
- Removable drip tray
- Removable grill with plastic handles
- 2 pairs of U-rails to adjust the level of the grill
- Inclusive crumb tray
- Weight: 15 kg
- Dimensions: W 600mm x T 360mm x H 315mm
- temp. +35 / +120 °C
- Conn.: 230 V - 50 Hz - 2,5 kW

Origin Portugal

customs tariff no. 85167200

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. 458-1025

Item/Model SARO Salamander Grill
model ATHENA

GTIN 4017337048656



Safety and Warning Instructions

- Place the device exclusively on a stable, level, and heat-resistant surface.
- Ensure that the mains voltage matches the specifications on the rating plate.
- Children and unauthorized persons must not operate the device or be left unattended near it.
- **During operation, the device's surfaces, particularly the tray and heating elements, can become very hot – risk of burns.** Use appropriate protective gloves.
- Never clean the device with a water jet or immerse it in liquids to avoid short circuits and electric shocks.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- Do not operate the device near flammable materials or in damp environments.
- Do not block or cover the ventilation openings to prevent overheating.
- Do not operate the device with a damaged cable or plug.
- Repairs must only be carried out by qualified personnel.
- Before operation, ensure that the tray is properly inserted.
- Do not switch the device on or off with wet hands to avoid the risk of electric shock.
- Regularly clean the device, particularly the tray and rack, to maintain hygienic conditions.
- The device is intended exclusively for gratinating food; any other use may cause damage and compromise safety.
- Do not use extension cords or T-adapters to connect the device.
- Dispose of packaging materials safely and keep them out of reach of children, as they pose a suffocation hazard.
- If water enters the device, disconnect it from the power supply and ensure it is completely dry before the next use.
- Do not leave the device unattended during operation.

Origin Portugal

customs tariff no. 85167200

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827