

TECHNICAL DATA SHEET

Order No. 458-1020

Item/Model SARO Toaster
model DABUR

GTIN 4017337048649



- Material: stainless steel
- crumb tray
- For up to 6 toasts per grid
- Upper / lower heat can be switched on separately (3 levels)
- Modern design
- Dim.: W 535 x D 270 x H 365 mm
- Grid: W 395 x D 210 mm
- Connection: 230 V - 50 Hz - 3.3 kW

Origin Portugal

customs tariff no. 85167200

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. 458-1020

Item/Model SARO Toaster
model DABUR

GTIN 4017337048649



Safety and Warning Instructions

- Place the device exclusively on a stable, level, and heat-resistant surface.
- Ensure that the mains voltage matches the specifications on the rating plate.
- Children and unauthorized persons must not operate the device or be left unattended near it.
- **During operation, the device's surfaces, particularly the housing and tray, can become very hot – risk of burns. Use appropriate protective gloves.**
- Never clean the device with a water jet or immerse it in liquids to avoid short circuits and electric shocks.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- Do not block or cover the ventilation openings to prevent overheating.
- Repairs must only be carried out by qualified personnel using original spare parts.
- If visible damage or malfunctions occur, stop operation immediately and contact qualified personnel.
- Dispose of packaging materials safely and keep them out of reach of children, as they pose a suffocation hazard.
- The device is intended exclusively for toasting bread. Any other use may cause damage and compromise safety.
- Ensure the power cord does not run over sharp edges or come into contact with hot surfaces.
- Clean the housing and removable trays only when they are cool to avoid burns.
- Do not switch the device on or off with wet hands.
- Regularly clean the device to maintain hygienic conditions. Use a damp cloth and avoid abrasive cleaning agents.
- Ensure the power plug is always easily accessible to quickly disconnect the device from the power supply in case of emergency.

Origin Portugal

customs tariff no. 85167200

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827