

## TECHNICAL DATA SHEET

Order No. 429-4000

Item/Model SARO Convection oven  
model TERNI

GTIN 4017337429066



- Material: stainless steel
- Double-glazed door
- 4 plain trays W 435 x D 315 mm included
- Distance between trays 75 mm
- Double fan for even heat distribution
- Timer: 0 - 120 minutes
- Weight: 40 kg
- Dimensions: W 595mm x T 600mm x H 580mm
- temp. +60/+300 °C
- Conn.: 230 V - 50 Hz - 2,67 kW

Origin China

customs tariff no. 85141980

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 \* Geschäftsführer: Dominique de Charry, Aloys de Charry  
ID-Nr. DE 120061194 \* St.-Nr. 116/5718/0194 \* ILN 4017337000005 \* WEEE-Reg.-Nr. DE 58229827

## SAFETY & WARNING INSTRUCTIONS

Order No. 429-4000

Item/Model SARO Convection oven  
model TERNI

GTIN 4017337429066



### Safety and Warning Instructions

- Place the device exclusively on a stable, level, and heat-resistant surface.
- Ensure that the mains voltage matches the specifications on the rating plate.
- Children and unauthorized persons must not operate the device or be left unattended near it.
- **During operation, the housing surface and doors can become very hot – risk of burns. Use appropriate protective gloves.**
- Never clean the device with a water jet or immerse it in liquids to avoid short circuits and electric shocks.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- Maintain a minimum distance of 10 cm on the sides and 15 cm at the back to ensure adequate air circulation.
- **Hot air and moisture are released from the rear vent – handle the device carefully to avoid burns.**
- Do not store flammable or explosive materials near the device. A safety distance of at least 50 cm from flammable materials is required.
- If visible damage or malfunctions occur, stop operation immediately and contact qualified personnel.
- The power plug should always be easily accessible to quickly disconnect the device from the power supply in case of emergency.
- Repairs must only be carried out by qualified personnel.
- Use the device only for cooking, baking, or reheating food. Any other use may cause damage and void the warranty.
- After transport or storage at low temperatures, allow the device to reach room temperature before operation to avoid condensation issues.
- Regularly clean the interior to prevent burned-on food residues.
- Do not place objects on top of the device during operation, as they may become hot and cause damage.
- Do not cool the glass door with cold water, as this may cause stress cracks.
- Dispose of packaging materials safely, as they pose a suffocation hazard for children.

Origin China

customs tariff no. 85141980

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 \* Geschäftsführer: Dominique de Charry, Aloys de Charry  
ID-Nr. DE 120061194 \* St.-Nr. 116/5718/0194 \* ILN 4017337000005 \* WEEE-Reg.-Nr. DE 58229827