

TECHNICAL DATA SHEET

Order No. 443-2105

Item/Model SARO bread toaster
model ALAVA

GTIN 4017337071845



- Material: (housing) stainless steel
- Top and bottom heat
- Timer
- Crumb tray
- Quartz heating element ensures consistent results
- Temperature range: up to +250 °C
- **Connection: 230 V - 50 Hz – 2.1 kW**
- Dimensions: W 442 x D 280 x H 276 mm
- Weight (net/gross): 7.5 / 9.4 kg

Origin China

customs tariff no. 85167200

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. 443-2105

Item/Model SARO bread toaster
model ALAVA

GTIN 4017337071845



Safety and Warning Instructions

- Place the device exclusively on a stable, level, and heat-resistant surface.
- The device is intended for indoor use only and for food preparation methods such as grilling, baking, roasting, and toasting. Any other use may cause damage and compromise safety.
- Installation and repairs must only be carried out by a qualified technician. Do not remove any components of the device yourself.
- **During operation, the device's surfaces can become very hot – risk of burns. Use appropriate protective gloves.**
- Never clean the device with a water jet or immerse it in liquids to avoid short circuits and electric shocks.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- Do not block or cover the ventilation openings or the surface of the device to prevent overheating.
- If visible damage or malfunctions occur, immediately stop operation and contact qualified personnel.
- Dispose of packaging materials safely and keep them out of reach of children, as they pose a suffocation hazard.
- Children must not operate the device and should be supervised to ensure they do not play with it.
- Ensure that the power plug is always easily accessible to quickly disconnect the device from the power supply in case of an emergency.
- Use only original spare parts and recommended accessories to ensure the safety and functionality of the device.
- Do not insert food into the device before preheating it according to the operating instructions (first use should be empty).
- Regularly empty and clean the crumb tray to maintain hygienic conditions.
- Do not operate the device outdoors or in damp environments.
- Maintain a safe distance from walls and flammable materials to avoid fire hazards.
- Do not leave the device unattended during operation.
- Repairs must only be carried out by qualified personnel to avoid electrical hazards.
- Regular inspections by competent personnel are recommended to ensure the electrical safety of the device.

Origin China

customs tariff no. 85167200

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827