

TECHNICAL DATA SHEET

Order No. **502-1010**

Item/Model **SARO patio heater
model Sunset 2000**

GTIN **8713415335163**



- Material: (housing) metal, black stove-enamelled
- Patio heater as a standing model, with protective grille
- For commercial use in outdoor areas
- Lamp: halogen
- On/off switch also available directly on the device
- Incl. remote control (2x AAA each 1.5 V - not included)
- Anti-tip: 3 foot anchor brackets included
- Supplied disassembled, assembly required
- Protection class: IPX4
- Range: approx. 16 m²
- Power levels: 3 (800 W, 1200 W, 2000 W)
- Cable length: 1.5 m with CEE 7/4 plug (Type F/Schuko plug)
- Connection: 230 V - 50 Hz - 2 kW
- Dimensions: diam. 470 (shade: dia. 420) x H 2300 mm
- Weight (net/gross): 14.1 / 15.4 kg

Origin China

customs tariff no. 85162999

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. **502-1010**

Item/Model **SARO patio heater
model Sunset 2000**

GTIN **8713415335163**



Safety and Warning Instructions

- The patio heater is designed exclusively for outdoor use. Do not use in enclosed or damp indoor spaces like bathrooms or laundry rooms.
- Keep flammable objects such as tarpaulins, umbrellas, furniture, or paper at least 1 meter away from the device.
- The heater must be securely mounted.
- During operation, the heating cap becomes extremely hot. Do not touch the device to avoid the risk of burns.
- Do not spray or clean the device with water. Ensure that no liquids come into contact with electrical parts.
- Use the heater only with grounded outlets that are equipped with a residual current device (RCD).
- Do not leave the device unattended while in operation.
- Do not place objects on the heater or cover it, as this can cause overheating and a fire hazard.
- Children under 3 years old should not be near the device. Children between 3 and 8 years old may only be near the device under supervision and with appropriate instructions.
- If damage to the device, cord, or outlet is detected, immediately disconnect the device from the power supply and do not use it further.
- Always switch off the device, disconnect it from the power supply, and allow it to cool completely before cleaning or maintaining it.
- Use only original spare parts and have maintenance performed exclusively by qualified personnel.
- Do not use near easily flammable substances such as gas or solvents. Explosion hazard!
- The heater should never be positioned to emit heat upward to avoid overheating the ceiling.
- During installation or disassembly, ensure the device is disconnected from the power supply.
- Dispose of packaging materials safely and keep them out of reach of children, as they may pose a suffocation hazard.

Origin China

customs tariff no. 85162999

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827