

TECHNICAL DATA SHEET

Order No. **366-2610**

Item/Model **SARO Hot buffet
model PREMIUM LINE SB-H 200 OAK**

GTIN **4017337068425**



- **Material:** Basin 304 stainless steel, body MDF with foil coating
- **17 cm thick granite plate**
- **Fixed glass sneeze guard**
- **Space for plates**
- **Includes wheels, lighting, and drain tap**
- **Color:** Oak with black granite plate
- **Temperature range:** +30 / +90 °C
- **Delivered without GN containers**
- **Capacity:** 5x 1/1 GN, depth up to 150 mm
- **Connection:** 220-240 V / 1 Ph. / 50 Hz / 3.00 kW
- **Dimensions:** W 2000 x D 880 x H 1350 mm
- **Weight (net/gross):** 200 / 245 kg

Origin Turkey

customs tariff no. 85167970

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. **366-2610**

Item/Model **SARO Hot buffet
model PREMIUM LINE SB-H 200 OAK**

GTIN **4017337068425**



Safety and Warning Instructions

- Place the device exclusively on a stable, level, and non-slip surface.
- Before connecting, ensure that the mains voltage (230 V / 50 Hz) matches the specifications on the rating plate.
- Ensure that the ventilation slots are free from obstructions to allow adequate air circulation and prevent overheating.
- Do not operate the device near heat sources, direct sunlight, or in humid environments.
- Children and unauthorized persons must not operate the device or remain unsupervised nearby.
- During operation, the surfaces of the device can become very hot—risk of burns. Wear appropriate heat-resistant gloves when handling hot food or surfaces.
- Do not store or use flammable, explosive, or chemical substances inside or near the device.
- Never clean the device with a water jet or immerse it in liquids to avoid the risk of short circuits and electric shock.
- Always switch off the device, disconnect it from the power supply, and allow it to cool completely before cleaning, maintenance, or extended periods of non-use.
- The device is designed exclusively for the storage and presentation of warm food. Any other use may cause damage and void the warranty.
- After a power outage or disconnection from the power supply, wait at least 5 minutes before switching the device back on to prevent damage to the heating element.
- If visible damage is found on the device or cable, immediately stop operation and contact qualified personnel.
- Repairs must only be carried out by qualified personnel using original spare parts.
- Do not use adapters, extension cords, or multi-socket outlets to avoid overheating and fire hazards.
- Ensure that the power plug is always easily accessible to quickly disconnect the device from the power supply in an emergency.
- Dispose of packaging materials safely and keep them out of reach of children, as they pose a suffocation hazard.

Origin Turkey

customs tariff no. 85167970

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827