

TECHNICAL DATA SHEET

Order No. **443-1000**

Item/Model **SARO Electric contact grill
model PG 1**

GTIN **4017337035717**



- Material: (housing and dripping tray) stainless steel,, (plate) cast iron, (handle) heat-resistant plastic
- Grooved plate
- Removable drip tray
- Plates are easy to clean
- Weight: 16 kg
- temp. +50 / +300 °C
- Conn.: 230 V - 50 Hz - 1,8 kW

Origin China

customs tariff no. 85166070

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. **443-1000**

Item/Model **SARO Electric contact grill
model PG 1**

GTIN **4017337035717**



Safety and Warning Instructions

- Place the device only on a stable, level, and non-slip surface.
- Ensure that the mains voltage corresponds to the information on the nameplate.
- Children and unauthorized persons must not operate the device or be left unsupervised near it.
- During operation, the surfaces of the device, especially the grill plates, can become very hot – there is a risk of burns. Use appropriate protective gloves.
- Never clean the device with a water jet or immerse it in liquids, as there is a risk of short circuits and electric shock.
- Always switch off the device, disconnect it from the power supply, and allow it to cool down completely before cleaning, maintenance, or extended periods of non-use.
- When opening the grill, always use the heat-insulated plastic handle to avoid burns to your hands.
- Do not store flammable liquids, gases, or other combustible items near the grill, as the casing can become very hot.
- Do not operate the device unattended; always switch it off before leaving the room.
- Repairs must only be carried out by qualified personnel using original spare parts.
- Use the device only for its intended purpose, such as grilling fish, meat, or vegetables.
- Before first use and after extended storage, check the device for functionality.
- Ensure that the power cord is undamaged, does not run over sharp edges, and does not come into contact with hot surfaces.
- Clean the grill plates after use to prevent the buildup of grease and food residues.
- Safely dispose of packaging materials like plastic and Styrofoam, as they pose a suffocation hazard to children.

Origin China

customs tariff no. 85166070

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827