

TECHNICAL DATA SHEET

Order No. 443-1050

Item/Model SARO Electric Salamander
model LANA

GTIN 4017337035779



- Material: (housing) stainless steel, (grid) chrome plated steel,, (handle) heat resistant plastic
- 4 pairs of u-rails to adjust the level of the grid
- 1 grid included
- Pull-out crumb tray
- Timer: 30 minutes
- Weight: 17,5 kg
- Dimensions: W 580mm x T 400mm x H 375mm
- temp. +50 / +300 °C
- Conn.: 230 V - 50 Hz - 3 kW

Origin China

customs tariff no. 85166070

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. 443-1050

Item/Model SARO Electric Salamander
model LANA

GTIN 4017337035779



Safety and Warning Instructions

- Place the device exclusively on a stable, level, and heat-resistant surface.
- Ensure that the mains voltage matches the specifications on the rating plate.
- Children and unauthorized persons must not operate the device or be left unattended near it.
- **During operation, the device's surfaces, particularly the grill plates, can become very hot – risk of burns. Use appropriate protective gloves.**
- Never clean the device with a water jet or immerse it in liquids to avoid short circuits and electric shocks.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- Ensure the device is placed on a dry, non-slip surface to maintain stability.
- Do not move or tilt the device during operation to prevent injuries or damage.
- Repairs must only be carried out by qualified personnel.
- If visible damage or malfunctions occur, stop operation immediately and contact the dealer or qualified personnel.
- Use only original accessories and spare parts to ensure the safety and functionality of the device.
- The device is designed exclusively for its intended purpose, such as gratinating or browning food. Any other use may cause damage and void the warranty.
- Dispose of packaging materials such as plastic and styrofoam safely and keep them out of reach of children, as they pose a suffocation hazard.
- During the first use, the device may emit smoke or odors due to protective coatings. Let the device heat up for approximately 20 minutes without food and then clean it again.
- Ensure the power plug is always easily accessible to quickly disconnect the device from the power supply in case of emergency.

Origin China

customs tariff no. 85166070

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827