

TECHNICAL DATA SHEET

Order No. **443-10001**

Item/Model **SARO Contact Grill
model PG 1 GG**

GTIN **4017337070367**



- Material: (housing and Drip Tray) stainless steel, (Grill Plate) Cast iron, (Handle) Heat-insulating plastic
- Top grill plate ribbed and bottom plate smooth
- Grill plates are easy to clean
- Temperature range: +50 / +300 °C
- Top grill plate: W 213 x D 215 mm
- Bottom grill plate: W 220 x D 230 mm
- External dimensions: W 320 x D 384 x H 203 mm
- Connection: 230 V - 50 Hz - 1.8 kW
- Weight (net/gross): 16 / 17 kg

Origin China

customs tariff no. 85166070

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. **443-10001**

Item/Model **SARO Contact Grill
model PG 1 GG**

GTIN **4017337070367**



Safety and Warning Instructions

- Place the device only on a stable, level, and non-slip surface.
- Ensure that the mains voltage corresponds to the information on the nameplate.
- Children and unauthorized persons must not operate the device or be left unsupervised near it.
- During operation, the surfaces of the device, especially the grill plates, can become very hot – there is a risk of burns. Use appropriate protective gloves.
- Never clean the device with a water jet or immerse it in liquids, as there is a risk of short circuits and electric shock.
- Always switch off the device, disconnect it from the power supply, and allow it to cool down completely before cleaning, maintenance, or extended periods of non-use.
- When opening the grill, always use the heat-insulated plastic handle to avoid burns to your hands.
- Do not store flammable liquids, gases, or other combustible items near the grill, as the casing can become very hot.
- Do not operate the device unattended; always switch it off before leaving the room.
- Repairs must only be carried out by qualified personnel using original spare parts.
- Use the device only for its intended purpose, such as grilling fish, meat, or vegetables.
- Before first use and after extended storage, check the device for functionality.
- Ensure that the power cord is undamaged, does not run over sharp edges, and does not come into contact with hot surfaces.
- Clean the grill plates after use to prevent the buildup of grease and food residues.
- Safely dispose of packaging materials like plastic and Styrofoam, as they pose a suffocation hazard to children.

Origin China

customs tariff no. 85166070

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827