

TECHNICAL DATA SHEET

Order No. **441-1015**

Item/Model **SARO Chamber Vacuum Machine
modell LECCE 2**

GTIN **4017337035588**



- Material: stainless steel
- Vacuum pump: 12 m3/h
- Sealing bar: 410 mm
- Digital control
- For vacuum bags with a maximum width of 400 mm
- Weight: 50.5kg
- Chamber dimensions: W441 x D449 x H170 mm
- External dimensions: W 535 x D 591 x H 438 mm
- Connection: 230 V - 50 Hz - 0.75 kW

Origin Italy

customs tariff no. 84141089

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. **441-1015**

Item/Model **SARO Chamber Vacuum Machine
modell LECCE 2**

GTIN **4017337035588**



Safety and Warning Instructions

- Place the device only on a stable, level, and non-slip surface.
- Ensure that the mains voltage corresponds to the information on the nameplate.
- Children and unauthorized persons must not operate the device or be left unsupervised near it.
- During operation, the surfaces of the device, especially the sealing bar, can become very hot – there is a risk of burns.
- Never clean the device with a water jet or immerse it in liquids to avoid the risk of short circuits and electric shock.
- Always switch off the device, disconnect it from the power supply, and allow it to cool down completely before cleaning, maintenance, or extended periods of non-use.
- The device must not be used to process liquids or moist foods to avoid damage caused by suction.
- Regularly inspect the power cord for damage; in case of defects, have it replaced only by qualified personnel.
- Immediately stop operation if visible damage or malfunctions occur, and contact qualified personnel.
- Repairs must only be carried out by authorized personnel to ensure safety and maintain the warranty.
- Safely dispose of packaging materials, as they pose a suffocation hazard to children.
- The device is intended exclusively for vacuum packaging dry foods and materials; any other use may cause damage and void the warranty.
- Ensure the power plug is always accessible to quickly disconnect the device from the power supply in case of an emergency.
- Keep the area around the device free of flammable materials or liquids.
- Before first use and after extended storage, check the device for functionality according to the instructions.

Origin Italy

customs tariff no. 84141089

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Klevé HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827