

TECHNICAL DATA SHEET

Order No. 16-2220

Item/Model SARO Choco Dispenser
model EDU-SRW-1KB-3-V

GTIN 4017337070282



- Material: Stainless steel and polypropylene
- Stand with dispenser for holding buckets Type F (3 liters)
- 2 locking clips for secure bucket placement
- Simple and efficient filling of croissants, donuts, etc. with pudding or chocolate cream
- Adjustable dosing from approx. 12 to 20 g
- Heating surface with a diameter of 95 mm and temperature limitation to 60 °C
- Suitable for colder ambient temperatures
- Small rubber feet on the stand protect the work surface
- Delivered without bucket
- **Connection: 230V – 50 Hz - 0.150 kW**
- Dimensions: W 165 x D 290 x H 420 mm
- Weight (net/gross): 3.4 / 3.91 kg

Origin Netherlands

customs tariff no. 85167970

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. 16-2220

Item/Model SARO Choco Dispenser
model EDU-SRW-1KB-3-V

GTIN 4017337070282



Safety and Warning Instructions

- The device is intended exclusively for professional use indoors and must be placed on a stable, level, and heat-resistant surface.
- Ensure that the power source meets the required specifications.
- **During operation, the surfaces of the device, especially the container and outlet, can become very hot—risk of burns.**
- The device should only be used with food products such as chocolate, sauces, or other liquid or semi-solid products. Any other use may cause damage or compromise safety.
- Never clean the device with a water jet or immerse it in liquids, as electrical components could be damaged.
- Always switch off the device, unplug it, and allow it to cool completely before cleaning or performing maintenance.
- Regular cleaning of the container and outlet is required to maintain hygienic conditions and ensure smooth operation.
- If visible damage or malfunctions occur, immediately stop operation and contact qualified personnel.
- Repairs and maintenance should only be carried out by authorized personnel using original spare parts.
- Ensure that no foreign objects enter the dispenser, as this can cause blockages and damage.
- Never leave the device unattended while in operation, especially when filled.
- Dispose of packaging materials safely to avoid suffocation hazards for children.
- Regularly check the power cord for damage. If visible damage is found, do not use the device.
- The dispenser should not be operated near heat sources or in damp environments.
- Ensure that the device is completely emptied and cleaned after use to prevent residue that could affect functionality.

Origin Netherlands

customs tariff no. 85167970

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827