

## TECHNICAL DATA SHEET

Order No. 172-2030

Item/Model SARO Fryer

model PROFRI 4

GTIN 4017337172306



- Material: stainless steel
- Rounded, removable basin with cooling zone
- Variable temperature adjustment
- Removable heating elements ensure easy cleaning
- Safety thermostat
- Size incl. side handles
- Weight: 5 kg
- Dimensions: W 245mm x T 430mm x H 310mm
- Capacity: 4 liter
- temp. 0 / +180 °C
- Conn.: 230 V 50/60 Hz 2 kW

Origin Italy customs tariff no. 85167920

Stand: 06.03.2025

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY



## SAFETY & WARNING INSTRUCTIONS

Order No. 172-2030

Item/Model SARO Fryer

model PROFRI 4

GTIN 4017337172306



## Safety and Warning Instructions

- Place the device only on a stable, level, and non-slip surface.
- Before first use, thoroughly clean the basin and the fryer basket to remove any residue from industrial oils.
- Only connect to a grounded 230 V socket, and do not use extension cords or adapters.
- Before use, ensure that the oil reaches the minimum fill level indicated by the markings.
- Do not mix different types of oil or fat to avoid dangerous overflowing.
- Do not move or tilt the device during operation to prevent hot oil from spilling.
- Never extinguish hot fat or oil with water; in case of fire, smother the flames with a damp cloth.
- After use, turn off the device, unplugit, and allow it to cool down before cleaning.
- Do not use aggressive or abrasive cleaners; clean the device with a damp cloth and mild detergent.
- Regularly filter the oil and thoroughly clean the basin to remove food residue and extend the lifespan of the device.
- Only trained personnel should operate the device, and they must have read the safety and operating instructions.
- Keep children away from the device and never leave it unattended.
- Do not operate the device outdoors or in humid environments.

Origin Italy customs tariff no. 85167920

Stand: 06.03.2025

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY