

## TECHNICAL DATA SHEET

Order No. 330-3760

Item/Model SARO Dry Aging Cabinet

model DA 480

GTIN 4017337071067



- Material: (Housing) stainless steel; (Interior) plastic (antibacterial)
- Lockable door, double-tempered glass
- Digital temperature control
- Temperature range: 0 25°C, humidity (30% 90%)
- LED lighting 0.4 W (separately switchable)
- Ultraviolet system, separately switchable
- No tank or fixed water connection required
- Includes salt container and activated carbon filter
- Air circulation cooling with fan
- Includes 3 height-adjustable shelves, W 571 x D 451.5 mm + 2 meat hooks
- Fixed meat hook holder, load capacity up to 80 kg per hook
- 4 feet, 2 adjustable
- Temperature range: 0 / +25 °C
- Connection: 230 240 V 50 Hz 0.139 kW
- Capacity: 480 liters
- Interior dimensions: W 572 x D 710 x H 1362 mm
  Exterior dimensions: W 700 x D 810 x H 1662 mm
- Weight (net/gross): 122 / 137 kg
- Refrigerant: R290

Origin China customs tariff no. 84181020

Stand: 06.03.2025

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY



## SAFETY & WARNING INSTRUCTIONS

Order No. 330-3760

Item/Model SARO Dry Aging Cabinet

model DA 480

GTIN 4017337071067



## Safety and Warning Instructions

- Place the device exclusively on a stable, level, and well-ventilated surface.
- The aging cabinet is intended for indoor use only and should be protected from direct sunlight, moisture, and heat sources.
- Ensure that the mains voltage matches the specifications on the rating plate.
- Children and unauthorized persons must not operate the device or be left unattended near it.
- The device must only be used for the aging of meat. Mixing different aging types, such as meat, cheese, or sausage, may lead to spoilage and hygiene issues.
- Do not block or cover the ventilation openings during operation to avoid overheating.
- The refrigerant is flammable. During transport and installation, ensure that the refrigerant circuit is not damaged.
- In case of a refrigerant leak, immediately ventilate the room, disconnect the device from the power supply, and avoid open flames or sparks.
- Repairs must only be carried out by qualified personnel.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- $Open \ the \ door \ only \ when \ necessary, \ as \ frequent \ opening \ can \ affect \ humidity, \ temperature, \ and \ the \ aging \ process.$
- The UV light in the device is used for air sterilization and should not be looked at directly. Do not remove safety covers
- The water tank must be regularly refilled with clean water to maintain proper humidity levels inside the device. Do not use dirty or contaminated water.
- There is a risk of injury from falling meat pieces or hooks exercise caution when loading and unloading the cabinet.
- The aging cabinet is equipped with an automatic defrost function. During defrost cycles, do not touch components, as they may become hot.
- Dispose of packaging materials safely, as they can pose a suffocation hazard.
- Regular cleaning of the interior, meat hooks, and racks is required to maintain hygienic conditions.
- If visible damage or malfunctions occur, immediately stop operation and contact qualified personnel.

Origin China customs tariff no. 84181020

Stand: 06.03.2025

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY