

## TECHNICAL DATA SHEET

Order No. 443-4005

Item/Model SARO Sous-Vide cooker

model RIVOLI

GTIN 4017337044788



- Material: stainless steal
- Inclusive circulation pump
- With drain cocks
- Digital display
- Adjustable time and temperature levels
- Inclusive separating grid
- With universal pluggable frame
- For 2/3 GN container
- Water filling: min. 7 to max. 14 litre
- Weight: 7 kg
- Dimensions: W 360mm x T 402mm x H 300mm
- temp. +45/+95 °C
- Conn.: 230 V 50 Hz 0,5 kW

Origin China customs tariff no. 85167970

Stand: 06.03.2025

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY



## SAFETY & WARNING INSTRUCTIONS

Order No. 443-4005

Item/Model SARO Sous-Vide cooker

model RIVOLI

GTIN 4017337044788



## Safety and Warning Instructions

- Place the device exclusively on a stable, level, and heat-resistant surface.
- Ensure that the mains voltage matches the specifications on the rating plate.
- Children and unauthorized persons must not operate the device or be left unattended near it.
- During operation, the device's surfaces and the water bath can become very hot risk of burns. Use appropriate protective gloves.
- Never clean the device with a water jet or immerse it in liquids to avoid short circuits and electric shocks.
- Before cleaning, maintenance, or extended periods of non-use, switch off the device, disconnect it from the power supply, and allow it to cool completely.
- The water bath must always be maintained within the minimum and maximum fill level limits to prevent damage to the device.
- Use only vacuum-sealed foods in the device to ensure hygienic conditions.
- Do not block the inlet and outlet of the circulation pump to ensure even heat distribution.
- Repairs must only be carried out by qualified personnel using original spare parts.
- If visible damage or malfunctions occur, stop operation immediately and contact qualified personnel.
- Regularly clean the device with a damp cloth and mild cleaning agent. Do not use abrasive cleaners, metal sponges, or aggressive chemicals to avoid damaging the surfaces.
- $Dispose \ of packaging \ materials \ safely \ and \ keep \ them \ out \ of \ reach \ of \ children, \ as \ they \ pose \ a \ suffocation \ hazard.$
- Do not leave the device unattended while it is switched on.
- The device is intended exclusively for professional use in gastronomy and should be operated in accordance with the operating instructions.
- $\hbox{-} Store the device in a well-ventilated, non-corrosive environment during extended periods of non-use. \\$
- Ensure the power plug is always accessible to quickly disconnect the device from the power supply in case of emergency.

Origin China customs tariff no. 85167970

Stand: 06.03.2025

Importer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY